



Installation Instructions

Compact™ I/O 1769-IR6 RTD/resistance Input Module

Inside

Module Overview.....	2
Module Installation.....	3
System Assembly.....	4
Mounting Expansion I/O	5
Replacing a Single Module within a System	7
Field Wiring Connections.....	8
I/O Memory Mapping	16
Specifications	19
Hazardous Location Considerations	22
Environnements dangereux	22
For More Information.....	23