

## For More Information

| For                                                                                                                  | Refer to this Document                                               | Pub. No.         |
|----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|------------------|
| Detailed information on installing, programming, and troubleshooting your Compact RTD/resistance Input module.       | Compact RTD/resistance Input Module User Manual                      | 1769-UM005A-EN-P |
| A more detailed description of how to install and use your Compact I/O with MicroLogix 1500 programmable controller. | MicroLogix 1500 Programmable Controllers User Manual                 | 1764-UM001A-US-P |
| Detailed information on programming your MicroLogix System                                                           | MicroLogix 1200 and MicroLogix 1500 Instruction Set Reference Manual | 1762-RM001B-US-P |
| A detailed description on how to install and use your Compact I/O with the 1769-ADN DeviceNet Adapter.               | 1769-ADN DeviceNet Adapter User Manual                               | 1769-UM001A-US-P |
| An overview of the MicroLogix 1500 system, including Compact I/O.                                                    | MicroLogix 1500 System Overview                                      | 1764-SO001B-EN-P |
| More information on proper wiring and grounding techniques.                                                          | Industrial Automation Wiring and Grounding Guidelines                | 1770-4.1         |

If you would like a manual, you can:

- download a free electronic version from the internet:  
**[www.ab.com/micrologix](http://www.ab.com/micrologix)** or **[www.theautomationbookstore.com](http://www.theautomationbookstore.com)**
- purchase a printed manual by:
  - contacting your local distributor or Rockwell Automation representative
  - visiting **[www.theautomationbookstore.com](http://www.theautomationbookstore.com)** and placing your order
  - calling 1.800.963.9548 (USA/Canada)  
or 001.330.725.1574 (Outside USA/Canada)